



HP PSC 2355 Reflective Document Mat Replacement

This guide demonstrates how to replace a damaged Reflective Document Mat, which is the white plastic backing for the scanner glass.

Written By: Amber Gabaldon



INTRODUCTION

A damaged reflective document mat can produce poor quality images. You can replace this mat in a few simple steps.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Scanner Lid



- Grasp the scanner lid cover from the front of the device and lift lid all the way up until it stands on its own.

Step 2



- With two hands, grasp the lid on both sides near the hinges and lift straight up to release the lid from each hinge.

Step 3 — Reflective Document Mat



- Once the lid has been removed, lay it on a flat surface with the white mat facing up.
- Using the flat end of a plastic spudger, pry the mat off at one of the front corners. Do this again for the other front corner.

Step 4



- Once both front corners have been released from the plastic clasps the rest of the mat should easily lift off.
- Recycle or discard the damaged mat.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-26 02:08:13 PM.